

EASY

INSTALLATION

The installation can be completed with just one person.



1. Mark the drill holes position on the climbing wall according to the climbing holds.
2. Drill holes according to the mark point, drill bit diameter the same as the screw bolt diameter.
3. Install the screw bolt across the flat washer, climbing holds and the wall holes in sequence to the weld nuts. (Weld nuts may need to be tapped into wood with hammer beforehand)
4. Tightened the screw bolt with the Wrench.

