

# SLACKLINE KIT WITH RATCHET

## INSTRUCTION GUIDE




### READ THESE INSTRUCTIONS CAREFULLY BEFORE USE.

Designed for one person to use at a time (200kgs-440lbs MAX).  
Recommended height 50cm (Children should be supervised by an adult at all times.)



**AGE** 5+    **MAX WEIGHT** 200 KGS | 440 LBS

**PACKAGE INCLUDE** 50 FT METERS SLACKLINE | 7.5 FT RATCHET LINE  
2 PC SLACKLINE TREE PROTECTOR | DRAWSTRING STORAGE BAG

### 1 HOW TO SET UP




Fold in half to keep the slackline flat.




Noose the ratchet end and long line around 2 suitable trees or anchor points minimum of 1m circumference. Set the height at no more than 50 cm high from the ground.

2




Feed line through the belt on the ratchet. Keep the line straight.

3




Pull through all the slack, until the line is tight.

4



Turn the ratchet over and unlock by pulling out the release lever.

5



Pull the handle up & down to tighten up the slackline.

6



Handle should be level with the line facing down.


Max of 50 cm high

Always use padding between the tree & line.

When the line is tight, ensure the ratchet is back into the locked position using the release lever


Slackline is now fully set-up and ready to use. **ENJOY!**

### 1 HOW TO RELEASE



Unlock the ratchet by pulling out the release lever firmly.

2



Firmly push the ratchet right back until the line "Snaps" loose.